



Photopique haut



Photopique haut

☐ Echec	Bino	☒	☐	☐	☐	☒	☒	☐	☐	☒	☐	☐
☐ Echec	Droite	☐	☐	☒	☒	☐	☐	☒	☒	☐	☒	☐
☐ Echec	Gauche	☒	☐	☐	☐	☒	☒	☐	☒	☐	☐	☐



	Gauche			Droite		
	10°	20°	30°	10°	20°	30°
Total	4	19	36	4	19	36
Testés	0	0	2	0	0	2
Non perçus	0	0	0	0	0	0